



ALODINE 5200

CONVERSION COATING PROCESS FOR ALUMINIUM

1. INTRODUCTION

Alodine 5200 treatment is a chromium free product and specifically formulated for treating aluminium and its alloys. Spray or immersion application may be used. The process provides an excellent base for organic finishes.

2. OPERATING SUMMARY

Chemical: Alodine 5200	Bath Preparation per 1000 litres: 15 to 75 litres (configuration dependant)
Operation and Control (Rinsable):	
Concentration (points)	35 to 15
Time (seconds)	5 to 180
pH	3.0 to 3.6
Temperature	20°C to 50°C

3. PROCESS

The complete process sequence normally consists of the following steps:

- A. Cleaning
- B. Water rinsing
- C. Treating with **Alodine 5200** solution
- D. Water Rinsing (preferred)
- E. **Deoxylyte 200NC** rinse (used for bare corrosion resistance)
- F. Water Rinsing
- G. Drying

4. MATERIALS

Alodine 5200 Make Up

Alodine 5220 Replenisher (optional)

Parco Neutralizer 700 (if rinsing after treatment)

Parcolene 95B Defoamer

Testing Reagents and Apparatus

5. EQUIPMENT

Process tank, housing, pumps and piping should be fabricated from 316L or 304L stainless steel. The 316L being preferred for maximum tank life. A secondary choice is 316 or 304 stainless steel fabricated with approved welding techniques. In spray applications, nozzles fabricated from 316 stainless steel are preferred.

Heat exchanger plates or other heating devices should be polished 316L stainless steel. All process circulation pump seals, valve seats, door seals, etc., which come into contact with the process solution and occasional acid equipment cleaners, should be EDPM, Viton™ or Teflon™.

Chemical feed pump parts and other elastomers which may come into contact with the concentrated replenishing chemical should be EDPM, Viton™ or Teflon™.

Support equipment available from Henkel Surface Technologies for this process includes: chemical feed pumps, level controls, transfer pumps and bulk storage tanks.

Our sales representative should be consulted for information on Henkel Surface Technologies automatic process control equipment for this process and any addition questions. In addition, the "Henkel Surface Technologies Equipment Design Manual" may be consulted.

All equipment which will be in contact with **Alodine 5200 Make Up** (or **5220 Replenisher**) or processing solution should be thoroughly cleaned prior to use with the process. This includes such items as chemical metering pumps, solution tank, spray nozzles, spray zone shields and housings. Our representative will supply a recommended clean-out procedure which may be followed.

6. SURFACE PREPARATION

Cleaning

All metal to be treated with the processing solution must be free from grease, oil and other foreign matter before the treatment. A complete line of cleaners is available and our representative will recommend the proper one for each installation.

Water Rinsing

After cleaning, the metal must be thoroughly rinsed with water. The rinse should be overflowed continuously at a rate which will keep it clean and free from scum and contamination.

ALODINE 5200

7. TREATING WITH THE ALODINE 5200 PROCESSING SOLUTION

Buildup

Recommended buildup is 15 to 75 litres of **Alodine 5200 Make Up** per 1000 litres of processing solution volume.

Fill the tank about three-fourths full with water. Add the proper amount of **Alodine 5200** and then add sufficient water to bring the solution up to the working level. Mix thoroughly and heat to the operating temperature. **Parcolene 95B Defoamer** must be used in spray applications. If bath foams, add 20 mls per 1000 litres of **Parcolene 95B** until foam subsides.

Operation

Time 5 seconds to 2.0 minutes
Temperature Ambient to 50°C

The solution concentration may be increased or reduced to meet specific line conditions. Our representative will assist in establishing the proper concentration.

Replenishment

Alodine 5200 Makeup or **Alodine 5220 Replenisher** will be used for replenishment, depending on the surface area of metal and type of work processed (the testing and control for both products is the same).

Our representative will recommend the proper replenisher for your system.

8. TESTING AND CONTROL

Never pipette by mouth, use a pipette filler.

Concentration

The concentration of the treatment solution is determined by a simple titration.

Since this is a reverse titration, the treatment bath is used to titrate the solution prepared below.

Pipette (or discharge from a burette) exactly 10 ml of Titrating Solution 15 into a 150 ml beaker, add 50 ml of water, then 5 ml of Reagent Solution 44. Titrate with the process bath until the pink colour just changes to colourless. Record mls of bath added as the concentration titration.

The concentration may be determined from the following table:

<u>Titration</u> <u>(ml)</u>	<u>Concentration %</u> <u>by volume</u>
26.7	1.5
20.0	2.2
14.7	3.0
10.8	4.5
9.8	6.0
7.8	7.5

Note: The greater the concentration, the lower the number of mls (points) of titration.

pH Adjustment

When **Alodine 5200** is used as a rinsable, reactive coating, during initial tank charge it is necessary to raise the pH of the bath to about 3 to prevent the treatment from etching the aluminium. It is normally required that **Parco Neutralizer 700** be added initially to a rinsable coating bath at 0.5 ml to 2 ml per 1000 litres of bath volume. If the product is used dry-in-place, no pH adjustment is used.

9. AFTER TREATMENT

Drying

Parts coming from the coating bath should be dried in an indirectly fired oven or by other means which will not contaminate the metal with fumes, oil or partially burned gasses.

Products with cavities or pockets which trap moisture should be blown dry with a jet of clean, compressed air.

If handling of the dried, unpainted work is necessary, operators should wear clean cotton gloves.

10. STORAGE REQUIREMENTS

Alodine 5200 should be protected from freezing. If the chemical is frozen, it will be irreversibly damaged and should not be used. **Alodine 5200** may precipitate if stored at temperatures below 4°C or above 40°C. The product must be stored between 40° and 100°F. If exposed to temperatures outside that range for short periods, the product should be immediately returned to the proper temperature and stirred.

11. WASTE DISPOSAL INFORMATION

Applicable regulations covering disposal and discharge of chemicals should be consulted and followed.

Disposal information for **Alodine 5200** and **Alodine 5220 Replenisher** is given on the Material Safety Data Sheet for each product.

The processing bath is pH 3 to 4 and contains fluorides. Waste treatment and neutralisation may be required prior to discharge to sewer.

12. PRECAUTIONARY INFORMATION

When handling the chemical product used in this process, the first aid and handling recommendations on the Material Safety Data Sheet for the product should be read, understood and followed.

The processing solution is acidic and may be irritating to skin and may cause burns to eyes. Avoid contact with skin and eyes. In case of contact follow the recommendations for contact given on the Material Safety Data Sheet for **Alodine 5200**.

ALODINE 5200

Testing Reagents and Apparatus

(Order only those items which are not already on hand).

<u>Quantity</u>	<u>Item</u>
1.....	Acid Dispensing Assembly
2*.....	Beaker, 150 ml
1.....	Burette Assembly, 25 ml Automatic
1.....	Flask, 100 ml, Glass, Volumetric
2*.....	Pipette, 10 ml Volumetric
1.....	Pipette Filler
1.....	Jug, Graduated, Plastic
5 litre	Reagent Solution 44 (50% H ₂ SO ₄)
1 litre	Titration Solution 15 (0.042N KMnO ₄)

* Includes one more than actually required, to allow for possible breakage.

DISCLAIMER

Any information given is, to the best of our knowledge, the best currently available, with respect to our products and their use, but it is subject to revision as additional knowledge and experience is gained. Such information is offered as a guideline for experimentation only and is not to be construed as a representation that the material is suitable for any particular purpose or use. Customers are encouraged to make their own enquiries as to the material's characteristics and, where appropriate, to conduct their own tests in the specific context of the material's intended use. This information is not a license to operate under nor is it intended to suggest infringement of any patent. We guarantee a uniform quality standard for this product. The only conditions and warranties accepted by Henkel in relation to this product or process are those implied by either Commonwealth or State statutes.