



Technologies

TECHNICAL INFORMATION WATERTREAT CHROME NEUTRALISER

1. INTRODUCTION

Henkel Technologies supplies a number of chromium containing compounds for various metal treatment procedures. From time-to-time, solutions or rinses containing these compounds may require dumping. Stringent pollution control regulations in many areas prohibit the disposal of hexavalent chromium compounds into sewage systems. This bulletin presents a simple and economical treatment process, which will provide environmentally treated waste water.

2. THE PROCESS

The process removes the chromium compounds via two steps. In the first step, the hexavalent chromium is reduced with **WATERTREAT CHROME NEUTRALISER**. The second step involves the formation of insoluble chromium hydroxides, which precipitate and settle to the bottom portion of the solution. The upper, chromium-free water, is safe to dump as waste water. The settled sludge is disposed of via a registered waste disposal company at regular intervals.

3. EQUIPMENT

The whole treatment operation may be carried out in one tank, e.g. the solution tank or rinse tank. However, sufficient time must be available for complete settling of the sludge. It is more convenient to transfer the treated water to another tank for settling so as not to hold up the use of the main solution tank. Adequate stirring must be available to dissolve the treatment products. Alternatively, treatment may be carried out in a continuous system, consisting of a pH adjustment and chrome reduction tank, a precipitation tank and a final settling tank.

4. TREATMENT PROCEDURE

- a. Chromate waste water is pumped into the treatment tank.
- b. The amount of hexavalent chromium in the solution is determined as outlined in Section 5.
- c. The amount of **WATERTREAT CHROME NEUTRALISER** required is then calculated as in Section 6.
- d. The solution is mixed thoroughly and the pH of the bath is maintained between 2.0 and 3.0 by the addition of the **WATERTREAT CHROME NEUTRALISER**. The bath will turn a dark blue-green colour as the chromium is reduced to the trivalent form. Allow at least 30 minutes for complete reduction. Complete reduction can be checked colorimetrically using s-diphenylcarbazide reagent. Add several drops of s-diphenylcarbazide reagent to a small sample of the solution. If any hexavalent chrome is present this solution will turn bright pink. If this occurs add a further addition of Watertreat Chrome Neutraliser and mix.

4. TREATMENT PROCEDURE Cont...

- e. The treated water may now be pumped over to the precipitation tank.
- f. **WATERTREAT M** or **CHROME PRECIPITATOR** is now added in sufficient quantity to raise the pH to between 7.0 and 8.0.
- g. The mixer is stopped and solids are allowed to settle. The clear water can then be pumped off into the regular sewage system. Settlement may take from hours to several days.
- h. The sludge can be scooped or shovelled into drums for pick up by a waste disposal company. The longer the solution is allowed to settle, the more compact the resulting sludge.

5. HEXAVALENT CHROMIUM TITRATION

The amount of hexavalent chromium present in the waste water is determined via the following procedure:

- a. Pipette a 5 mL sample of the waste water into a beaker or flask and dilute to approximately 100 mL.
- b. Add a few crystals or 5 mL of 20% Potassium Iodide solution.
- c. Add about 15 mL of concentrated Hydrochloric Acid or Sulphuric Acid to the flask and mix.
- d. After approximately one minute, titrate the solution with 0.1N Sodium Thiosulphate until a straw colour is obtained.
- e. Add several mL of soluble Starch Solution and continue the titration with 0.1N Sodium Thiosulphate until the blue-black colour disappears. (At the end point, a light green colour due to trivalent chromium will be evident.)
- f. Record the number of mL of 0.1N Sodium Thiosulphate used as hexavalent chromium titration.

Note: Where solutions contain only small amounts of hexavalent chromium, larger sample sizes are necessary, i.e. 25 mL or 100 mL. The titration obtained is then reduced proportionately, to that of a 5 mL sample size. (For a 5 mL sample, number of mL x 350 = ppm hexavalent chrome).

6. WATERTREAT CHROME NEUTRALISER REQUIRED

Add 6.0 mL of **WATERTREAT CHROME NEUTRALISER** per Litre of waste water for each mL of hexavalent chromium titration.

Example: A 100 mL sample titrated 4 mL. Therefore, a 5mL sample would have titrated 1/20 of that value, or 0.20 mL. Theoretically, this solution would require about 1.2 mL of **WATERTREAT CHROME NEUTRALISER** per Litre of waste solution.

DISCLAIMER

Any information given is, to the best of our knowledge, the best currently available, with respect to our products and their use, but it is subject to revision as additional knowledge and experience is gained. Such information is offered as a guideline for experimentation only and is not to be construed as a representation that the material is suitable for any particular purpose or use. Customers are encouraged to make their own enquiries as to the material's characteristics and, where appropriate, to conduct their own tests in the specific context of the material's intended use. This information is not a license to operate under nor is it intended to suggest infringement of any patent. We guarantee a uniform quality standard for this product. The only conditions and warranties accepted by Henkel in relation to this product or process are those implied by either Commonwealth or State statutes.